


04apr07 tilt sensor az swings before/after td change PITCH – (c0+c1\*az from fit)



04apr07 tilt sensor az swings before/after td change Roll – (c0+c1\*az from fit)

