









Monitor 5 points on platform. Distance moved since first day




Monitor 2 points on azArm. Distance moved since first day









Monitor Azimuth angle for 5 points on platform. Az Angle moved since first day (uncorrected)



Monitor azimuth angle for 2 points on azArm. Az Angle moved since first day (uncorrected)



Monitor Az Reference prism change: (after-before) pntMeasure.



Check Az diff between RefPrisms for daily motion

