


04apr07 tilt sensor az swings before/after td change PITCH - (c0+c1*az from fit)



04apr07 tilt sensor az swings before/after td change Roll - (c0+c1*az from fit)

