

## Installation of ModLon Gateway Kit 541-0717

### ModBus ASCII for TP/XF-78 Devices / ModBus RTU for FT-10 Devices

#### GENERAL INFORMATION

This instruction sheet describes the installation of a ModLon Gateway kit in TP/XF-78 and FT-10 networks. The following parts are included in this kit.

Part Description	Qty
ModLon Gateway	1
Power Supply	1
Straight-Through Cable	1
CD (for FT-10 installations using LonMaker for Windows)	1
Network Terminator (TP/XF-78)	1

**NOTE:** If the ModLon Gateway is located at the end of the TP/XF-78 network data bus, you will need the TP/XF-78 network terminator, included in this kit.

**NOTE:** If your installation includes FT-10 network multidrop bus topology, you will need two multidrop bus terminators (Onan Part Number 300-5729), not included in this kit.

In addition to physical connections, this instruction sheet also includes information on binding and register mapping of the following modules to a ModLon Gateway.

#### TP/XF-78 Networks:

- Genset Communications Module (GCM)
- Controls Communications Module (CCM)
- Digital I/O Module (DIM)

#### FT-10 Networks:

- Controls Communications Module – Genset (CCM-G)
- Controls Communications Module – ATS (CCM-T)
- Digital I/O Module (DIM)

PowerCommand is a registered trademark of Cummins Inc.

LonWorks is a registered trademark and LonMaker is a trademark of Echelon Corporation.

Windows is a registered trademark of Microsoft Corporation.

ModBus and ModScan are registered trademarks of Schneider Electric.

WinZip is a registered trademark of WinZip Computing, Inc.

#### REQUIRED SOFTWARE

The following software is required to incorporate this kit into your network.

#### TP/XF-78 Networks:

- LonMaker™ for DOS Software (Onan Part Number PCLN 100P 1A)  
**NOTE:** LonMaker for Windows® can also be used for TP/XF-78 networks.
- Device Monitoring Software – Since data is supplied in ASCII format, select software that includes the following communications parameters: baud rate 9600, word length 7, parity Even, stop bits 1.

If ModScan® software is selected to monitor devices, see the “Optional Software” listed below and the information included under “Using ModScan Software,” starting on Page 11.

- WinZip® – Software used to decompress downloaded files.

#### FT-10 Networks:

- LonMaker for Windows
- Device Monitoring Software – Since data is supplied in RTU format, select software that includes the following communications parameters: baud rate 9600, word length 8, parity None, stop bits 1.

If ModScan® software is selected to monitor devices, see the “Optional Software” listed below and the information included under “Using ModScan Software,” starting on Page 18.

- WinZip® – Software used to decompress downloaded files.

## OPTIONAL SOFTWARE

- ModScan Software – Used to verify communications between the PCC network devices and the ModLon

A fully functional demo version of ModScan software can be downloaded from the Internet at <http://www.Win-Tech.com>. Click on the “Free Trial Demos” button. Under “Win32 ModBus® Applications,” click on the ModScan32.zip file and select an appropriate file location to store the software.


## DESCRIPTION

The ModLon Gateway provides a direct Echelon LonWorks® network interface to any device that can communicate:

- ModBus ASCII – TP/XF-78 networks
- ModBus RTU – FT-10 networks

This module translates LonWorks network protocol into ModLon ASCII or RTU. Figure 1 is a block diagram of the ModLon Gateway.


Refer to the *PowerCommand ® Network Installation and Operation Manual* (900-0366 for TP/XF-78 networks or 900-0529 for FT-10 networks) for instructions on network topology, wiring, and software installation.



**FIGURE 1. MODLON GATEWAY BLOCK DIAGRAM**

The ModLon Gateway (see Figure 2) has a network connector on one end for connection to network data and a DB9 connector on the other end for connection to an RS-232 port.

Externally the ModLon Gateway has a DC power input jack, a SERVICE pushbutton, and a SERVICE LED indicator.



**FIGURE 2. MODLON GATEWAY OUTLINE DRAWING**

The ModLon Gateway does not contain a terminate circuit.

## TP/XF-78 Networks

If the ModLon Gateway is located at the end of the TP/XF-78 network data bus, you will need the TP/XF-78 network terminator (Onan Part Number 300-5252) included in this kit. When the network terminator is required, connect the two orange wires to the "A" and "B" connections and the green/yellow wire to the ground connection (see Figure 3).

## FT-10 Networks

For free topology FT-10 networks, only one device on each segment must be terminated. Some network devices (including the CCM-G, CCM-T, and DIM modules) include a device terminator switch which can be used for this type of termination.

FT-10 network multidrop bus topology requires termination at each end of the bus using multidrop bus terminators (Onan Part Number 300-5729 – not included in this kit). When the network terminator is required, connect the two orange wires to the "A" and "B" connections and the green/yellow wire to the ground connection (see Figure 3).




FIGURE 3. NETWORK TERMINATOR INSTALLATION

## MODLON GATEWAY INSTALLATION

If there is a site network installation drawing, refer to it for the ModLon Gateway location. If a site network installation drawing is not available, refer to the *PowerCommand Network Installation and Operation Manual* (900-0366 for TP/XF-78 networks or 900-0529 for FT-10 networks) for network topology and maximum network length. **All wiring must follow a specific network topology and must fall within distance limits.** Refer to individual instruction sheets for information on installing additional network devices.

Choose a clean, flat, vibration-free mounting surface. Avoid locations that are hot, damp, or dusty. The temperature range must not exceed 32°F (0°C) to 158°F (70°C).

## Power Supply

The ModLon Gateway has a DC power input jack that connects to utility power through a plug-in transformer, supplied with this kit (see Figure 4).

Locate the ModLon Gateway near an electrical outlet. If the ModLon Gateway must remain powered during an electrical power failure, use an uninterruptable power supply (UPS). Refer to the PowerCommand Network Installation and Operation Manual (900-0366 for TP/XF-78 networks or 900-0529 for FT-10 networks) for UPS information. If more than one device will be connected to the UPS, purchase a multioutlet adapter or multioutlet extension cord.




FIGURE 4. MODLON POWER AND PC CONNECTIONS

## NETWORK TOPOLOGY AND DATA MEDIA

Refer to the “Network Hardware and Wiring” section of the PowerCommand Network Installation and Operation Manual for information on the network topology and data transmission media.

**WARNING** *AC voltages and currents present an electrical shock hazard that can cause severe personal injury or death. Only trained, experienced personnel are to perform the following procedures.*

### Connections

Network data connections are made at the network connector for LonWorks network data, and at a DB9 connector (Port A) for connection to an RS-232 port. (Connectors are shown in Figure 2. The cable supplied with the ModLon Gateway is shown in Figure 4.)

### SERVICE SWITCH AND LED

The Service push button is used during installation (when prompted by the LonMaker program). **It is important to press the service switch on the ModLon Gateway that is part of the permanent site. The service switch should be pressed only during installation.**

The green LED indicates if the service push button is being pressed. The LED indicator blinks when the

ModLon Gateway is unconfigured and is off if the ModLon Gateway is configured. The LED indicator remains on if an unrecoverable error is detected.

## NETWORK INSTALLATION

Read the “Introduction” and “Network Hardware and Wiring” sections of the *PowerCommand Network Installation and Operation Manual* (900-0366 for TP/XF-78 networks or 900-0529 for FT-10 networks) before constructing the network.

### TP/XF-78 Networks

The “Network Installation – LonMaker” section of the *TP/XF-78 PowerCommand Network Installation and Operator’s Manual* (900-0366) provides a detailed description of the network installation process, including the following step-by-step installation procedures:

1. Setting up Network Installation Tools
2. Starting LonMaker Software
3. Using LonMaker Software
4. LonMaker Network Setup
5. Connecting Devices with LonMaker
6. Installing Devices with LonMaker
7. Testing Devices and Verifying Installation

Possible bindings to a ModLon Gateway are shown in Table 1.

**TABLE 1. TP/XF-78 NETWORK MODLON BINDINGS**

**GCM ModBus Interface (ModLon):**

Possible bindings to a ModBus Interface (ModLon):

<b>PCC w/GCM</b>	<b>ModLon</b>		
<i>nviRunCmd</i>	← <i>nvoRunCmd[..]</i>	<i>General</i>	<b>Control</b>
<i>nviResetCmd</i>	← <i>nvoResetCmd[..]</i>		
<i>nviEmerStopCmd</i>	← <i>nvoEStopCmd[..]</i>		
<i>nvoStatus</i>	→ <i>nviGCMStatus[..]</i>	<i>General</i>	<b>Monitor</b>
<i>nvoGenData</i>	→ <i>nviGCMACData[..]</i>		
<i>nvoEngineData</i>	→ <i>nviGCMEngData[..]</i>		

**CCM ModBus Interface (ModLon):**

Possible bindings to the ModLon Interface (v1):

<b>CCM</b>	<b>Master Control</b>		
<i>nviRelayControl1</i>	← <i>nvoCCMControl1[..]</i>	<i>“Load Shed”</i>	<b>Control</b>
<i>nviRelayControl2</i>	← <i>nvoCCMControl2[..]</i>	<i>“Test”</i>	
<i>nviRelayControl3</i>		<i>“Transfer Inhibit”</i>	
<i>nvoACData</i>	→ <i>nviCCMACData[..]</i>	<i>General</i>	<b>Monitor</b>
<i>nvoNodeStatus</i>	→ <i>nviCCMStatus[..]</i>		
<i>nvoSensorData</i>	→ <i>nviCCMEngData[..]</i>		

**DIM ModBus Interface (ModBus):**

Possible bindings to a ‘new’ ModLon Interface:

<b>ModLon</b>	<b>DIM</b>		
<i>nvoSNVTState[..]</i>	→ <i>nvi16RelayA</i>	<i>16 Relays</i>	<b>Control</b>
<i>nviDIMStatus[..]</i>	← <i>nvoNodeStatus</i>	<i>Node</i>	<b>Status</b>

## **FT-10 Networks**

The “Using LonMaker for Windows” section of the *FT-10 PowerCommand Network Installation and Operation Manual* (900-0529) provides a detailed description of the network installation process, including the following step-by-step installation procedures:

1. Setting up Network Installation Tools
2. Registering Plug-Ins
3. Using LonMaker for Windows Software
4. LonMaker for Windows Network Setup

5. Adding Devices with LonMaker for Windows
6. Installing Bindings with LonMaker for Windows
7. Installing Software Upgrades to an Existing Network

FT-10 networks include four possible ModLon options. A device template is available in LonMaker for Windows for each of these options. Use the files on the CD included with this kit.

Possible bindings to a ModLon Gateway are shown in Tables 2 (Option 1), 3 (Option 2), and 4 (Option 3A), and 5 (Option 3B).

**TABLE 2. FT-10 NETWORK MODLON BINDINGS – OPTION 1**

**CCM-G ModBus Interface (ModLon):**

Possible bindings to a ModBus Interface (ModLon):

<b>PCC w/CCM-G</b>	<b>ModLon</b>		
<i>nviStartCmd</i>	← <i>nvoGenStartCmd[..]</i>	<i>General</i>	<b>Control</b>
<i>nviFaultResetCmd</i>	← <i>nvoFaultResetCmd[..]</i>		
<i>nvoGenStatus</i>	→ <i>nviGenStatus[..]</i>	<i>General</i>	<b>Monitor</b>
<i>nvoGenACData</i>	→ <i>nviGenACData[..]</i>		
<i>nvoGenEngData</i>	→ <i>nviGenEngData[..]</i>		

**CCM-T ModBus Interface (ModLon):**

Possible bindings to the ModLon Interface (v1):

<b>CCM-T</b>	<b>Master Control</b>		
<i>nviTestCmd</i>	← <i>nvoCCMTestCmd[..]</i>	<i>“Load Shed”</i>	<b>Control</b>
<i>nviFaultResetCmd</i>	← <i>nvoCCMResetCmd[..]</i>	<i>“Test”</i>	
		<i>“Transfer Inhibit”</i>	
<i>nvoACDataLoad</i>	→ <i>nviCCMACDataLoad[..]</i>	<i>General</i>	<b>Monitor</b>
<i>nvoATSStatus</i>	→ <i>nviCCMACStatus[..]</i>		
<i>nvoACDataSrc1</i>	→ <i>nviCCMACDataSrc1[..]</i>		
<i>nvoACDataSrc2</i>	→ <i>nviCCMACDataSrc2[..]</i>		

**DIM ModBus Interface (ModBus):**

Possible bindings to a ModLon Interface:

<b>ModLon</b>	<b>DIM</b>		
<i>nvo16RelayA[..]</i>	→ <i>nvi16RelayA</i>	<i>16 Relays</i>	<b>Control</b>
<i>nviDIMStatus[..]</i>	← <i>nvoIOSTatus</i>	<i>Node</i>	<b>Status</b>

**TABLE 3. FT-10 NETWORK MODLON BINDINGS – OPTION 2**

**CCM-G ModBus Interface (ModLon):**

Possible bindings to a ModBus Interface (ModLon):

<b>PCC w/CCM-G</b>	<b>ModLon</b>		
<i>nviStartCmd</i>	← <i>nvoGenStartCmd[..]</i>	<i>General</i>	<b>Control</b>
<i>nviFaultResetCmd</i>	← <i>nvoFaultResetCmd[..]</i>		
<i>nvoGenStatus</i>	→ <i>nviGenStatus[..]</i>	<i>General</i>	<b>Monitor</b>
<i>nvoGenACData</i>	→ <i>nviGenACData[..]</i>		
<i>nvoGenEngData</i>	→ <i>nviGenEngData[..]</i>		
<i>nvoGenParaData</i>	→ <i>nviGenParaData[..]</i>		

**CCM-T ModBus Interface (ModLon):**

Possible bindings to the ModLon Interface (v1):

<b>CCM-T</b>	<b>Master Control</b>		
<i>nviTestCmd</i>	← <i>nvoCCMTestCmd[..]</i>	<i>“Load Shed”</i>	<b>Control</b>
<i>nviFaultResetCmd</i>	← <i>nvoCCMResetCmd[..]</i>	<i>“Test”</i>	
		<i>“Transfer Inhibit”</i>	
<i>nvoATSStatus</i>	→ <i>nviCCMACStatus[..]</i>		
<i>nvoACDataLoad</i>	→ <i>nviCCMACDataLoad[..]</i>		

**DIM ModBus Interface (ModBus):**

Possible bindings to a ModLon Interface:

<b>ModLon</b>	<b>DIM</b>		
<i>nvo16RelayA[..]</i>	→ <i>nvi16RelayA</i>	<i>16 Relays</i>	<b>Control</b>
<i>nviDIMStatus[..]</i>	← <i>nvoIStatus</i>	<i>Node</i>	<b>Status</b>

**TABLE 4. FT-10 NETWORK MODLON BINDINGS – OPTION 3A****CCM-G ModBus Interface (ModLon):**

Possible bindings to a ModBus Interface (ModLon):

<b>PCC w/CCM-G</b>	<b>ModLon</b>		
<i>nviStartCmd</i>	← <i>nvoGenStartCmd[..]</i>	<i>General</i>	<b>Control</b>
<i>nviFaultResetCmd</i>	← <i>nvoFaultResetCmd[..]</i>		
<i>nvoGenStatus</i>	→ <i>nviGenStatus[..]</i>	<i>General</i>	<b>Monitor</b>
<i>nvoGenACData</i>	→ <i>nviGenACData[..]</i>		
<i>nvoGenEngData</i>	→ <i>nviGenEngData[..]</i>		
<i>nvoGenParaData</i>	→ <i>nviGenParaData[..]</i>		

**TABLE 5. FT-10 NETWORK MODLON BINDINGS – OPTION 3B****CCM-T ModBus Interface (ModLon):**

Possible bindings to the ModLon Interface (v1):

<b>CCM-T</b>	<b>Master Control</b>		
<i>nviTestCmd</i>	← <i>nvoCCMTestCmd[..]</i>	<i>“Load Shed”</i>	<b>Control</b>
<i>nviFaultResetCmd</i>	← <i>nvoCCMResetCmd[..]</i>	<i>“Test”</i>	
		<i>“Transfer Inhibit”</i>	
<i>nvoACDataLoad</i>	→ <i>nviCCMACDataLoad[..]</i>	<i>General</i>	<b>Monitor</b>
<i>nvoATSSStatus</i>	→ <i>nviCCMACStatus[..]</i>		
<i>nvoACDataSrc1</i>	→ <i>nviCCMACDataSrc1[..]</i>		
<i>nvoACDataSrc2</i>	→ <i>nviCCMACDataSrc2[..]</i>		

## USING MODSCAN SOFTWARE

ModScan is a tool that can help you verify communications between the PowerCommand Network devices you have installed and the ModLon.

### Notes

The following notes apply to using ModScan with TP/XF-78 and FT-10 networks.

#### Genset Control

- Start/Stop – When this register is set to “1,” the genset starts, synchronizes, and closes its breaker. As long as this register remains a “1,” the genset will continue to run. When this register is set to “0,” the genset stops.
- Fault Reset – This should be a momentary signal of about 2 seconds duration. Entering a “1” in the fault reset register resets any non-active warning and, If there is not a remote start on the genset, it resets any non-active shutdown except the Emergency Stop.

- Emergency Stop (TP/XF-78 networks only) – When this register is set to “1,” the emergency stop is active at the PowerCommand control. The emergency stop cannot be rest until this register is set to “0.” After the register is reset to “0,” the emergency stop must be reset at the PowerCommand control. It cannot be reset remotely.

### Miscellaneous

- Fault State – As part of Gen Status State, digital value 4 (Fault State 1) = shutdown with an active run command (cannot be remotely reset) and digital value 5 (Fault State 2) = shutdown with no active run command (can be remotely reset).
- Fault Text (TP/XF-78 networks only) – These are 8 words (16 ASCII characters, 2 characters per word) that spell out the actual active fault.
- Genset Status Error – This a value that is not supported by the genset and therefore, has no meaning or function.




FIGURE 5. MAIN MODSCAN SCREEN

## TP/XF-78 Networks

Use ModScan software after this kit has been incorporated into your network. An RS-232 straight-through cable must be installed between the PC serial port and the RS-232 connector on the ModLon Gateway. Figure 5 shows the initial screen displayed upon launching the program.

1. From the tool bar, select Connection → Connect. The Connection Details dialog box is displayed (see Figure 6). The Device Id is 1.
2. Use the pull down menu under “Connect Using” to select the comm port you wish to use.
3. Click on the “Protocol Selections” button and verify that “STANDARD ASCII” is selected (see Figure 7).
4. Click “OK” on the two open dialog boxes.

You should notice in the upper right of the dialog box, the “Number of Polls” counter incrementing.

5. On the main ModScan screen (see Figure 8), Change the Address to 1001, the Length to 39,

and the Device ID to 1. From the MODBUS Point Type pull down menu, select “03: HOLDING REGISTER.”

The “Valid Slave Responses” should now be incrementing as the data on the screen is updated. The following are register addresses for Genset #1.

- 41029 is Oil Pressure
- 41030 is Oil Temp.
- 41031 is Coolant Temp. (L)
- 41032 is Coolant Temp. (R)
- 41033 is Exhaust Temp. (L)
- 41034 is Exhaust Temp. (R)
- 41035 is Battery Voltage
- 41036 is Engine Hours (tens)
- 41037 is Engine Hours (thousands)
- 41038 is Number of Starts
- 41039 is Engine Speed

Refer to the register mapping information (Tables 6, 7, and 8) to view different pieces of data.

6. On the main ModScan menu (see Figure 9), change the Length to 42. The “Valid Slave Responses” will stop incrementing and the error message shown in Figure 9 is displayed.




FIGURE 6. TP-78 NETWORK CONNECTION DETAILS DIALOG BOX




FIGURE 7. MODBUS PROTOCOL SELECTION DIALOG BOX





FIGURE 8. MODBUS POINT TYPE = HOLDING REGISTER



**FIGURE 9. ERROR MESSAGE**

**[WARNING]** *Accidental starting of the generator set can cause severe personal injury or death. During step 7, a “start” command is sent to the genset. If the genset Run/Off/Auto switch is in the Auto position, the genset WILL start.*


7. To output a value from the ModLon to a network device, double click on register 41040. The Write Register dialog box is displayed.

If you enter a value of “1” and select “Update,”

Genset #1 starts and runs. If you double click on register 41040 again, enter a value of “0,” and selecting “Update,” the Genset stops.

8. Review the mapping register information for other coils that you can manipulate.

By changing the Length on the main ModScan screen back to 39, the data registers will again update.



**FIGURE 10. WRITE COIL DIALOG BOX**

**TABLE 6. MODLON REGISTER MAPPING INFORMATION – TP/XF-78 NETWORK POWERCOMMAND GENSET**

Structure	Data Point	ModBus Registers					Scaling		
		GCM[0]	GCM[1]	GCM[2]	GCM[3]	GCM[4]	Multiplier	Offset	Units
Status	state <sup>1</sup>	41001	41101	41201	41301	41401			
	status <sup>2</sup>	41002	41102	41202	41302	41402			
	fault_type <sup>3</sup>	41003	41103	41203	41303	41403			
	fault_text[0,1]	41004	41104	41204	41304	41404			
	fault_text[2,3]	41005	41105	41205	41305	41405			
	fault_text[4,5]	41006	41106	41206	41306	41406			
	fault_text[6,7]	41007	41107	41207	41307	41407			
	fault_text[8,9]	41008	41108	41208	41308	41408			
	fault_text[10,11]	41009	41109	41209	41309	41409			
	fault_text[12,13]	41010	41110	41210	41310	41410			
	fault_text[14,15]	41011	41111	41211	41311	41411			
	fault_code*	41012	41112	41212	41312	41412			
	error	41013	41113	41213	41313	41413			
AC Data (Load)	volts_a	41014	41114	41214	41314	41414			VAC
	volts_b	41015	41115	41215	41315	41415			VAC
	volts_c	41016	41116	41216	41316	41416			VAC
	freq	41017	41117	41217	41317	41417	0.1		Hz
	amps_a	41018	41118	41218	41318	41418			A
	amps_b	41019	41119	41219	41319	41419			A
	amps_c	41020	41120	41220	41320	41420			A
	percent_amps_a	41021	41121	41221	41321	41421	0.005		%
	percent_amps_b	41022	41122	41222	41322	41422	0.005		%
	percent_amps_c	41023	41123	41223	41323	41423	0.005		%
	total_pf	41024	41124	41224	41324	41424	0.00005		
	total_kw	41025	41125	41225	41325	41425			kW
	percent_kw	41026	41126	41226	41326	41426	0.005		%
	total_kvar	41027	41127	41227	41327	41427			kVAR
	total_mwh	41028	41128	41228	41328	41428			MWh
Engine Data	oil_press	41029	41129	41229	41329	41429	0.1		PSI
	oil_temp	41030	41130	41230	41330	41430	0.1		F
	coolant_temp1	41031	41131	41231	41331	41431	0.1		F
	coolant_temp2	41032	41132	41232	41332	41432	0.1		F
	exhaust_temp1	41033	41133	41233	41333	41433	0.1		F
	exhaust_temp2	41034	41134	41234	41334	41434	0.1		F
	battery_volts	41035	41135	41235	41335	41435	0.1		VDC
	runtime_hrs	41036	41136	41236	41336	41436	0.1		h
	runtime_khrs	41037	41137	41237	41337	41437	1000		h
	engine_starts	41038	41138	41238	41338	41438			
	engine_rpm	41039	41139	41239	41339	41439	0.1		rpm
Genset Control	Start/Stop	41040	41140	41240	41340	41440			
	Reset	41041	41141	41241	41341	41441			
	Emergency Stop	41042	41142	41242	41342	41442			

\* Fault codes are listed in the genset Operator's/Service Manuals.

Data = Multiplier x (Register + Offset)

1 State	
Digital Value	Description
0	Power Up
1	Stopped
2	Cranking
3	Running
4	Shutdown with Run
5	Shutdown without Run

2 Status				
Data Point	Bit	PCC 2100	PCC 3100	PCC 3200
Common Alarm	0 (LSB)	N/A	X	N/A
Load Dump	1	N/A	X	N/A
Genset CB Position	2	N/A	X	N/A
Leading Power Factor	3	X	X	X
Ready To Load	4	N/A	X	N/A
Control Switch – Run	5	X	X	X
Control Switch – Auto	6	X	X	X
Genset Start Delay	7	N/A	X	N/A
Genset Stop Delay	8	N/A	X	N/A
Load Demand	9	N/A	X	N/A
Paralleling Genset	10	N/A	X	N/A
Remote Start	11	N/A	N/A	N/A
Right Coolant Sensor	12	N/A	N/A	N/A
Exhaust 1 Installed	13	N/A	X	N/A
Exhaust 2 Installed	14	N/A	X	N/A
Genset CB Inhibit	15 (MSB)	N/A	X	N/A

3 Fault Type	
Digital Value	Description
0	Normal
1	Warning
2	Shutdown

**TABLE 7. MODLON REGISTER MAPPING INFORMATION – TP/XF-78 NETWORK  
DIGITAL INPUT/OUTPUT MODULE**

Structure	Data Point	ModBus Register	
		DIM[0]	DIM[1]
Node Status	relay 1, relay 2	42001	42101
	relay 3, relay 4	42002	42102
	relay 5, relay 6	42003	42103
	relay 7, relay 8	42004	42104
	relay 9, relay 10	42005	42105
	relay 11, relay 12	42006	42106
	relay 13, relay 14	42007	42107
	relay 15, relay 16	42008	42109
	input 1, input 2	42009	42109
	input 3, input 4	42010	42110
Relay Control	All 16 Relays	42011	42111

**TABLE 8. MODLON REGISTER MAPPING INFORMATION – TP/XF-78 NETWORK  
CONTROLS COMMUNICATION MODULE**

Structure	Data Point	ModBus Register					Scaling		
		CCM[0]	CCM[1]	CCM[2]	CCM[3]	CCM[4]	Multiplier	Offset	Units
Node Status	inputs 1..16	40001	40101	40201	40301	40401			
	inputs 17..32	40002	40102	40202	40302	40402			
	relay 1, relay 2	40003	40103	40203	40303	40403			
	relay 3, relay 4	40004	40104	40204	40304	40404			
AC Data (Load)	volts_a	40005	40105	40205	40305	40405			VAC
	volts_b	40006	40106	40206	40306	40406			VAC
	volts_c	40007	40107	40207	40307	40407			VAC
	freq	40008	40108	40208	40308	40408	0.1		Hz
	amps_a	40009	40109	40209	40309	40409			A
	amps_b	40010	40110	40210	40310	40410			A
	amps_c	40011	40111	40211	40311	40411			A
	percent_amps_a	40012	40112	40212	40312	40412	0.005		%
	percent_amps_b	40013	40113	40213	40313	40413	0.005		%
	percent_amps_c	40014	40114	40214	40314	40414	0.005		%
	total_pf	40015	40115	40215	40315	40415	0.00005		
	total_kw	40016	40116	40216	40316	40416			kW
	percent_kw	40017	40117	40217	40317	40417	0.005		%
	total_kvar	40018	40118	40218	40318	40418			kVAR
	total_mwh	40019	40119	40219	40319	40419			MWh
Engine Data (Genset Only)	temp1	40020	40120	40220	40320	40420	0.1		F
	temp2	40021	40121	40221	40321	40421	0.1		F
	temp3	40022	40122	40222	40322	40422	0.1		F
	oil_press	40023	40123	40223	40323	40423	0.1		PSI
	spare1	40024	40124	40224	40324	40424	0.1		User-Defined
	spare2	40025	40125	40225	40325	40425	0.1		User-Defined
	battery_volts	40026	40126	40226	40326	40426	0.1		VDC
Relay Control	Control1	40027	40127	40227	40327	40427			
	Control2	40028	40128	40228	40328	40428			
							Data = Multiplier x (Register + Offset)		

## FT-10 Networks

Use ModScan software after this kit has been incorporated into your network. An RS-232 straight-through cable must be installed between the PC serial port and the RS-232 connector on the ModLon

Gateway. Figure 11 shows the initial screen displayed upon launching the program.

1. From the tool bar, select Connection → Connect. The Connection Details dialog box is displayed (see Figure 12). The Device Id is 1.




FIGURE 11. MAIN MODSCAN SCREEN





FIGURE 12. FT-10 NETWORK CONNECTION DETAILS DIALOG BOX

2. Use the pull down menu under “Connect Using” to select the comm port you wish to use.

For FT-10 networks, configuration should be set to Baud Rate: 9600, Word Length: 8, Parity: None, and Stop Bits: 1, as shown in Figure 12.

Use the pull down menus to change these settings as necessary.

3. Click on the “Protocol Selections” button and change the Transmission Mode to “RTU” (see Figure 13). Click “OK.”



**FIGURE 13. MODBUS PROTOCOL SELECTION DIALOG BOX**

- Click “OK” on the two open dialog boxes.

You should notice in the upper right of the dialog box, the “Number of Polls” counter incrementing.

- On the main ModScan screen (see Figure 14), Change the Address to 1001, the Length to 49 (ModLon Mapping Option 1 Rev B) or 65 (ModLon Mapping Option 2 Rev B, ModLon Mapping Option 3 Rev B), and the Device ID to 1. From the MODBUS Point Type pull down menu, select “03: HOLDING REGISTER.”

The “Valid Slave Responses” should now be incrementing as the data on the screen is updated. The following are register addresses for Genset #1.

41036 is Oil Pressure

41037 is Oil Temp.

41038 is Coolant Temp. (L)

41039 is Misc. Temp 1

41040 is Misc. Temp 2

41041 is Fuel Rate

41042 is Engine RPM

41043 is Engine Starts

41044 is Eng Runtime (high)

41045 is Eng Runtime (low)

41046 is Total kwh (high)

Refer to the register mapping information (Tables 9 thru 16) to view different pieces of data.

- On the main ModScan menu (see Figure 15), change the Length to 49.




FIGURE 14. MODBUS POINT TYPE = HOLDING REGISTER

**WARNING** Accidental starting of the generator set can cause severe personal injury or death. During step 7, a “start” command is sent to the genset. If the genset Run/Off/Auto switch is in the Auto position, the genset WILL start.

7. To output a value from the ModLon to a network device, double click on register 40050. The Write Register dialog box is displayed.

If you enter a value of “1” and select “Update,”

Genset #1 starts and runs. If you double click on register 40050 again, enter a value of “0,” and selecting “Update,” the Genset stops.

8. Review the mapping register information for other coils that you can manipulate.

By changing the Length on the main ModScan screen back to 49, the data registers will again update.




FIGURE 15. WRITE COIL DIALOG BOX

**TABLE 9. MODLON REGISTER MAPPING INFORMATION – FT-10 NETWORK (OPTION 1)  
SINGLE POWERCOMMAND GENSET (CCM-G) (SHEET 1 OF 2)**

Structure	Data Point	ModBus Registers					Scaling		
		GEN[0]	GEN[1]	GEN[2]	GEN[3]	GEN[4]	Multiplier	Offset	Units
nvoGenStatus	Name [0,1]	40001	40101	40201	40301	40401			
	Name [2,3]	40002	40102	40202	40302	40402			
	Name [4,5]	40003	40103	40203	40303	40403			
	Name [6,7]	40004	40104	40204	40304	40404			
	Name [8,9]	40005	40105	40205	40305	40405			
	Name [10,11]	40006	40106	40206	40306	40406			
	Name [12,13]	40007	40107	40207	40307	40407			
	Name [14,15]	40008	40108	40208	40308	40408			
	Device Type	40009	40109	40209	40309	40409			
	Control Switch	40010	40110	40210	40310	40410			
	State <sup>1</sup>	40011	40111	40211	40311	40411			
	Fault Code*	40012	40112	40212	40312	40412			
	Fault Type <sup>2</sup>	40013	40113	40213	40313	40413			
	Percent kW	40014	40114	40214	40314	40414	0.5		%
	Total kW	40015	40115	40215	40315	40415			
	NFPA 110 <sup>3</sup>	40016	40116	40216	40316	40416			
	Extended <sup>4</sup>	40017	40117	40217	40317	40417			
nvoGenACData	Frequency	40018	40118	40218	40318	40418	0.1		Hz
	Total pf	40019	40119	40219	40319	40419	0.00005		PF
	Total kva	40020	40120	40220	40320	40420	1.0		KVA
	Total kW	40021	40121	40221	40321	40421	1.0		KW
	Total kvar	40022	40122	40222	40322	40422	1.0		KVAR
	Volts ab	40023	40123	40223	40323	40423	1.0		Volts
	Volts bc	40024	40124	40224	40324	40424	1.0		Volts
	Volts ca	40025	40125	40225	40325	40425	1.0		Volts
	Volts a	40026	40126	40226	40326	40426	1.0		Volts
	Volts b	40027	40127	40227	40327	40427	1.0		Volts
	Volts c	40028	40128	40228	40328	40428	1.0		Volts
	Amps a	40029	40129	40229	40329	40429	1.0		Amps
	Amps b	40030	40130	40230	40330	40430	1.0		Amps
	Amps c	40031	40131	40231	40331	40431	1.0		Amps
	Percent Amps a	40032	40132	40232	40332	40432	0.5		%
	Percent Amps b	40033	40133	40233	40333	40433	0.5		%
	Percent Amps c	40034	40134	40234	40334	40434	0.5		%

\* Fault codes are listed in the genset Operator's/Service Manuals.

Data = Multiplier x (Register + Offset)

**TABLE 9. MODLON REGISTER MAPPING INFORMATION – FT-10 NETWORK (OPTION 1)  
SINGLE POWERCOMMAND GENSET (CCM-G) (SHEET 2 OF 2)**

Structure	Data Point	ModBus Registers					Scaling		
		GEN[0]	GEN[1]	GEN[2]	GEN[3]	GEN[4]	Multiplier	Offset	Units
nvoGenEngData	Battery Voltage	40035	40135	40235	40335	40435	0.1		Volts DC
	Oil Pressure	40036	40136	40236	40336	40436	0.1		KPA
	Oil Temp (see Note 2)	40037	40137	40237	40337	40437	0.1		Deg Kelvin
	Coolant Temp	40038	40138	40238	40338	40438	0.1		Deg Kelvin
	Misc Temp 1 (see Note 4)	40039	40139	40239	40339	40439	0.1		Deg Kelvin
	Misc Temp 2 (see Note 4)	40040	40140	40240	40340	40440	0.1		Deg Kelvin
	Fuel Rate (see Note 3)	40041	40141	40241	40341	40441	0.01		GPH
	Engine RPM	40042	40142	40242	40342	40442	1.0		RPM
	Engine Starts	40043	40143	40243	40343	40443	1.0		starts
	Eng Runtime (High) (see Notes 1 and 5)	40044	40144	40244	40344	40444			
	Eng Runtime (Low)	40045	40145	40245	40345	40445	0.1		Sec
	Total kwh (High) (see Note 1)	40046	40146	40246	40346	40446			
	Total kwh (Low)	40047	40147	40247	40347	40447	1.0		kwh
	Total Fuel (High) (see Notes 1 and 3)	40048	40148	40248	40348	40448			
	Total Fuel (Low)	40049	40149	40249	40349	40449	0.01		Gal
Genset Control	Start/Stop	40050	40150	40250	40350	40450			
	Reset	40051	40151	40251	40351	40451			

\* Fault codes are listed in the genset Operator's/Service Manuals.

Data = Multiplier x (Register + Offset)

NOTES:

- For the Data Points Engine Runtime, the Total kwh and Total Fuel for the two registers designated as high and low are put together as an unsigned double integer. This is accomplished by multiplying the value in the high register by 65536 and adding it to the value in the low register. Most software packages automatically perform this calculation if the value is simply identified as an unsigned double integer.
- Value not supported in the 3200 controller.
- Value not supported in the 3100 controller.
- Value not supported.
- With 3100 and 2100 controllers, the units are hours. With the 3200 controller, the units are seconds. The multiplier is always 0.1. For all 3100 controllers, the values given are based on using EEPROM firmware, version 2.0 or greater. The values for Engine Runtime and Total kwh are not available on QST-30 gensets.

<sup>1</sup> <b>State</b>	
<b>Digital Value</b>	<b>Description</b>
0	Stopped
1	Start Pending
2	Warmup at Idle
3	Running
4	Cooldown at Rated
5	Cooldown at Idle

<sup>2</sup> <b>Fault Type</b>	
<b>Digital Value</b>	<b>Description</b>
0	Normal
1	Warning
2	Derate
3	Shutdown with Cooldown
4	Shutdown

<sup>3</sup> <b>NFPA110</b>	
<b>Description</b>	<b>Bit</b>
Normal Power	0 (MSB)
Genset Supplying Load	1
Genset Running	2
Not in Auto	3
High Battery Voltage	4
Low Battery Voltage	5
Charger AC Failure	6
Fail to Start	7
Low Coolant Temperature	8
Pre-High Engine Temperature	9
High Engine Temperature	10
Pre-Low Oil Pressure	11
Low Oil Pressure	12
Overspeed	13
Low Coolant Level	14
Low Fuel Level	15 (LSB)

<sup>4</sup> <b>Extended</b>	
<b>Description</b>	<b>Bit</b>
Check Genset	0 (MSB)
Ground Fault	1
High AC Voltage	2
Low AC Voltage	3
Under Frequency	4
Overload	5
Overcurrent	6
Short Circuit	7
Reverse KW	8
Reverse KVAR	9
Fail to Sync	10
Fail to Close	11
Load Demand	12
Genset Circuit Breaker Tripped	13
Utility Circuit Breaker Tripped	14
Emergency Stop	15 (LSB)

**TABLE 10. MODLON REGISTER MAPPING INFORMATION – FT-10 NETWORK (OPTION 1)  
AUTOMATIC TRANSFER SWITCH CONTROL COMMUNICATIONS MODULE (CCM-T) (SHEET 1 OF 2)**

Structure	Data Point	ModBus Registers					Scaling		
		NCM[0]	NCM[1]	NCM[2]	NCM[3]	NCM[4]	Multiplier	Offset	Units
nvoATSSStatus	Name [0,1]	41001	41101	41201	41301	41401			
	Name [2,3]	41002	41102	41202	41302	41402			
	Name [4,5]	41003	41103	41203	41303	41403			
	Name [6,7]	41004	41104	41204	41304	41404			
	Name [8,9]	41005	41105	41205	41305	41405			
	Name [10,11]	41006	41106	41206	41306	41406			
	Name [12,13]	41007	41107	41207	41307	41407			
	Name [14,15]	41008	41108	41208	41308	41408			
	Device Type	41009	41109	41209	41309	41409			
	Mode <sup>1</sup>	41010	41110	41210	41310	41410			
	State <sup>2</sup>	41011	41111	41211	41311	41411			
	Fault Code	41012	41112	41212	41312	41412			
	Fault Type <sup>3</sup>	41013	41113	41213	41313	41413			
	Percent Amps	41014	41114	41214	41314	41414	0.5		%
	Total kW	41015	41115	41215	41315	41415			
	NFPA 110 <sup>4</sup>	41016	41116	41216	41316	41416			
	Extended <sup>5</sup>	41017	41117	41217	41317	41417			
nvoACDataLoad	Frequency	41018	41118	41218	41318	41418	0.1		Hz
	Total pf	41019	41119	41219	41319	41419	0.00005		PF
	Total kva	41020	41120	41220	41320	41420	1.0		KVA
	Total kW	41021	41121	41221	41321	41421	1.0		KW
	Total kvar	41022	41122	41222	41322	41422	1.0		KVAR
	Volts ab	41023	41123	41223	41323	41423	1.0		Volts
	Volts bc	41024	41124	41224	41324	41424	1.0		Volts
	Volts ca	41025	41125	41225	41325	41425	1.0		Volts
	Volts a	41026	41126	41226	41326	41426	1.0		Volts
	Volts b	41027	41127	41227	41327	41427	1.0		Volts
	Volts c	41028	41128	41228	41328	41428	1.0		Volts
	Amps a	41029	41129	41229	41329	41429	1.0		Amps
	Amps b	41030	41130	41230	41330	41430	1.0		Amps
	Amps c	41031	41131	41231	41331	41431	1.0		Amps
	Percent Amps a	41032	41132	41232	41332	41432	0.5		%
	Percent Amps b	41033	41133	41233	41333	41433	0.5		%
	Percent Amps c	41034	41134	41234	41334	41434	0.5		%

Data = Multiplier x (Register + Offset)

**TABLE 10. MODLON REGISTER MAPPING INFORMATION – FT-10 NETWORK (OPTION 1)  
AUTOMATIC TRANSFER SWITCH CONTROL COMMUNICATIONS MODULE (CCM-T) (SHEET 2 OF 2)**

Structure	Data Point	ModBus Registers					Scaling		
		NCM[0]	NCM[1]	NCM[2]	NCM[3]	NCM[4]	Multiplier	Offset	Units
nvoACDataSrc1	Frequency	41035	41135	41235	41335	41435	0.1		Hz
	Total pf	41036	41136	41236	41336	41436	0.00005		PF
	Total kva	41037	41137	41237	41337	41437	1.0		KVA
	Total kW	41038	41138	41238	41338	41438	1.0		KW
	Total kvar	41039	41139	41239	41339	41439	1.0		KVAR
	Volts ab	41040	41140	41240	41340	41440	1.0		Volts
	Volts bc	41041	41141	41241	41341	41441	1.0		Volts
	Volts ca	41042	41142	41242	41342	41442	1.0		Volts
	Volts a	41043	41143	41243	41343	41443	1.0		Volts
	Volts b	41044	41144	41244	41344	41444	1.0		Volts
	Volts c	41045	41145	41245	41345	41445	1.0		Volts
	Amps a	41046	41146	41246	41346	41446	1.0		Amps
	Amps b	41047	41147	41247	41347	41447	1.0		Amps
	Amps c	41048	41148	41248	41348	41448	1.0		Amps
	Percent Amps a	41049	41149	41249	41349	41449	0.5		%
	Percent Amps b	41050	41150	41250	41350	41450	0.5		%
	Percent Amps c	41051	41151	41251	41351	41451	0.5		%
nvoACDataSrc2	Frequency	41052	41152	41252	41352	41452	0.1		Hz
	Total pf	41053	41153	41253	41353	41453	0.00005		PF
	Total kva	41054	41154	41254	41354	41454	1.0		KVA
	Total kW	41055	41155	41255	41355	41455	1.0		KW
	Total kvar	41056	41156	41256	41356	41456	1.0		KVAR
	Volts ab	41057	41157	41257	41357	41457	1.0		Volts
	Volts bc	41058	41158	41258	41358	41458	1.0		Volts
	Volts ca	41059	41159	41259	41359	41459	1.0		Volts
	Volts a	41060	41160	41260	41360	41460	1.0		Volts
	Volts b	41061	41161	41261	41361	41461	1.0		Volts
	Volts c	41062	41162	41262	41362	41462	1.0		Volts
	Amps a	41063	41163	41263	41363	41463	1.0		Amps
	Amps b	41064	41164	41264	41364	41464	1.0		Amps
	Amps c	41065	41165	41265	41365	41465	1.0		Amps
	Percent Amps a	41066	41166	41266	41366	41466	0.5		%
	Percent Amps b	41067	41167	41267	41367	41467	0.5		%
	Percent Amps c	41068	41168	41268	41368	41468	0.5		%
Control	Test	41069	41169	41269	41369	41469			
	Reset	41070	41170	41270	41370	41470			
							Data = Multiplier x (Register + Offset)		

<sup>1</sup> <b>Mode</b>	
<b>Digital Value</b>	<b>Description</b>
0	Test
1	Utility/Genset
2	Utility/Utility
3	Genset/Genset

<sup>2</sup> <b>State</b>	
<b>Digital Value</b>	<b>Description</b>
0	Neutral Position
1	Source 1 Connected
2	Source 2 Connected
3	Source 1 and 2 Connected

<sup>3</sup> <b>Fault Type</b>	
<b>Digital Value</b>	<b>Description</b>
0	No Faults
1	Warning

<sup>4</sup> <b>NFPA 110</b>	
<b>Description</b>	<b>Bit</b>
Source 1 Connected	0 (MSB)
Source 2 Connected	1
N/A	2
Not In Auto	3
N/A	4
N/A	5
Charger AC Failure	6
N/A	7
N/A	8
N/A	9
N/A	10
N/A	11
N/A	12
N/A	13
N/A	14
N/A	15 (LSB)

<sup>5</sup> <b>Extended</b>	
<b>Description</b>	<b>Bit</b>
Source 1 Available	0 (MSB)
Source 2 Available	1
Source 1 Connected	2
Source 2 Connected	3
ATS Common Alarm	4
Not In Auto	5
Test / Exercise in Progress	6
Low Battery Voltage	7
Load Shed	8
Transfer Inhibit	9
Retransfer Inhibit	10
Fail to Close	11
Fail to Disconnect	12
Fail to Synchronize	13
Bypass to Source 1	14
Bypass to Source 2	15 (LSB)

**TABLE 11. MODLON REGISTER MAPPING INFORMATION – FT-10 NETWORK (OPTION 1)  
DIGITAL INPUT/OUTPUT MODULE (DIM)**

Structure	Data Point	ModBus Register	
		DIM[0]	DIM[1]
nvoNodeStatus	relay 1	42000	42100
	relay 2	42001	42101
	relay 3	42002	42102
	relay 4	42003	42103
	relay 5	42004	42104
	relay 6	42005	42105
	relay 7	42006	42106
	relay 8	42007	42107
	relay 9	42008	42108
	relay 10	42009	42109
	relay 11	42010	42110
	relay 12	42011	42111
	relay 13	42012	42112
	relay 14	42013	42113
	relay 15	42014	42114
	relay 16	42015	42115
	input 1	42016	42116
	input 2	42017	42117
	input 3	42018	42118
	input 4	42019	42119
	input 5	42020	42120
	input 6	42021	42121
	input 7	42022	42122
	input 8	42023	42123
Control	nvi16RelayA	42024	42124

**TABLE 12. MODLON REGISTER MAPPING INFORMATION – FT-10 NETWORK (OPTION 2)  
PARALLELING POWERCOMMAND GENSET (CCM-G) (SHEET 1 OF 2)**

Structure	Data Point	ModBus Registers					Scaling		
		GEN[0]	GEN[1]	GEN[2]	GEN[3]	GEN[4]	Multiplier	Offset	Units
nvoGenStatus	Name [0,1]	40001	40101	40201	40301	40401			
	Name [2,3]	40002	40102	40202	40302	40402			
	Name [4,5]	40003	40103	40203	40303	40403			
	Name [6,7]	40004	40104	40204	40304	40404			
	Name [8,9]	40005	40105	40205	40305	40405			
	Name [10,11]	40006	40106	40206	40306	40406			
	Name [12,13]	40007	40107	40207	40307	40407			
	Name [14,15]	40008	40108	40208	40308	40408			
	Device Type	40009	40109	40209	40309	40409			
	Control Switch	40010	40110	40210	40310	40410			
	State <sup>1</sup>	40011	40111	40211	40311	40411			
	Fault Code*	40012	40112	40212	40312	40412			
	Fault Type <sup>2</sup>	40013	40113	40213	40313	40413			
	Percent kW	40014	40114	40214	40314	40414	0.5		%
	Total kW	40015	40115	40215	40315	40415			
	NFPA 110 <sup>3</sup>	40016	40116	40216	40316	40416			
	Extended <sup>4</sup>	40017	40117	40217	40317	40417			
nvoGenACData	Frequency	40018	40118	40218	40318	40418	0.1		Hz
	Total pf	40019	40119	40219	40319	40419	0.00005		PF
	Total kva	40020	40120	40220	40320	40420	1.0		KVA
	Total kW	40021	40121	40221	40321	40421	1.0		KW
	Total kvar	40022	40122	40222	40322	40422	1.0		KVAR
	Volts ab	40023	40123	40223	40323	40423	1.0		Volts
	Volts bc	40024	40124	40224	40324	40424	1.0		Volts
	Volts ca	40025	40125	40225	40325	40425	1.0		Volts
	Volts a	40026	40126	40226	40326	40426	1.0		Volts
	Volts b	40027	40127	40227	40327	40427	1.0		Volts
	Volts c	40028	40128	40228	40328	40428	1.0		Volts
	Amps a	40029	40129	40229	40329	40429	1.0		Amps
	Amps b	40030	40130	40230	40330	40430	1.0		Amps
	Amps c	40031	40131	40231	40331	40431	1.0		Amps
	Percent Amps a	40032	40132	40232	40332	40432	0.5		%
	Percent Amps b	40033	40133	40233	40333	40433	0.5		%
	Percent Amps c	40034	40134	40234	40334	40434	0.5		%

\* Fault codes are listed in the genset Operator's/Service Manuals.

Data = Multiplier x (Register + Offset)

**TABLE 12. MODLON REGISTER MAPPING INFORMATION – FT-10 NETWORK (OPTION 2)  
PARALLELING POWERCOMMAND GENSET (CCM-G) (SHEET 2 OF 2)**

Structure	Data Point	ModBus Registers					Scaling		
		GEN[0]	GEN[1]	GEN[2]	GEN[3]	GEN[4]	Multiplier	Offset	Units
nvoGenEngData	Battery Voltage	40035	40135	40235	40335	40435	0.1		Volts DC
	Oil Pressure	40036	40136	40236	40336	40436	0.1		KPA
	Oil Temp (see Note 2)	40037	40137	40237	40337	40437	0.1		Deg Kelvin
	Coolant Temp	40038	40138	40238	40338	40438	0.1		Deg Kelvin
	Misc Temp 1 (see Note 4)	40039	40139	40239	40339	40439	0.1		Deg Kelvin
	Misc Temp 2 (see Note 4)	40040	40140	40240	40340	40440	0.1		Deg Kelvin
	Fuel Rate (see Note 3)	40041	40141	40241	40341	40441	0.01		GPH
	Engine RPM	40042	40142	40242	40342	40442	1.0		RPM
	Engine Starts	40043	40143	40243	40343	40443	1.0		Starts
	Eng Runtime (High) (see Notes 1 and 5)	40044	40144	40244	40344	40444			
	Eng Runtime (Low)	40045	40145	40245	40345	40445	0.1		Sec
	Total kwh (High) (see Note 1)	40046	40146	40246	40346	40446			
	Total kwh (Low)	40047	40147	40247	40347	40447	1.0		KWH
	Total Fuel (High) (see Notes 1 and 3)	40048	40148	40248	40348	40448			
	Total Fuel (Low)	40049	40149	40249	40349	40449	0.01		Gal
nvoGenParaData	Frequency	40050	40150	40250	40350	40450	0.1		Hz
	Volts ab	40051	40151	40251	40351	40451	1.0		Volts
	Volts bc	40052	40152	40252	40352	40452	1.0		Volts
	Volts ca	40053	40153	40253	40353	40453	1.0		Volts
	Volts a	40054	40154	40254	40354	40454	1.0		Volts
	Volts b	40055	40155	40255	40355	40455	1.0		Volts
	Volts c	40056	40156	40256	40356	40456	1.0		Volts
	Customer Faults	40057	40157	40257	40357	40457			
	Network Faults	40058	40158	40258	40358	40458			
	Custom	40059	40159	40259	40359	40459			
	ES State <sup>5</sup>	40060	40160	40260	40360	40460			
	Load Share State <sup>6</sup>	40061	40161	40261	40361	40461			
	Load Govern State kw <sup>7</sup>	40062	40162	40262	40362	40462			
	Load Govern State kvar <sup>8</sup>	40063	40163	40263	40363	40463			
	Genset CB Position <sup>9</sup>	40064	40164	40264	40364	40464			
	Utility CB Position <sup>10</sup>	40065	40165	40265	40365	40465			
Genset Control	Start/Stop	40066	40166	40266	40366	40466			
	Reset	40067	40167	40267	40367	40467			

\* Fault codes are listed in the genset Operator's/Service Manuals.

Data = Multiplr x (Reg + Offset)

NOTES:

- For the Data Points Engine Runtime, the Total kwh and Total Fuel for the two registers designated as high and low are put together as an unsigned double integer. This is accomplished by multiplying the value in the high register by 65536 and adding it to the value in the low register. Most software packages automatically perform this calculation if the value is simply identified as an unsigned double integer.
- Value not supported in the 3200 controller.
- Value not supported in the 3100 controller.
- Value not supported.
- With 3100 and 2100 controllers, the units are hours. With the 3200 controller, the units are seconds. The multiplier is always 0.1. For all 3100 controllers, the values given are based on using EEPROM firmware, version 2.0 or greater. The values for Engine Runtime and Total kwh are not available on QST-30 gensets.

<sup>1</sup> State	
Digital Value	Description
0	Stopped
1	Start Pending
2	Warmup at Idle
3	Running
4	Cooldown at Rated
5	Cooldown at Idle

<sup>4</sup> Extended	
Description	Bit
Check Genset	0 (MSB)
Ground Fault	1
High AC Voltage	2
Low AC Voltage	3
Under Frequency	4
Overload	5
Overcurrent	6
Short Circuit	7
Reverse KW	8
Reverse KVAR	9
Fail to Sync	10
Fail to Close	11
Load Demand	12
Genset Circuit Breaker Tripped	13
Utility Circuit Breaker Tripped	14
Emergency Stop	15 (LSB)

<sup>3</sup> NFPA 110	
Description	Bit
Normal Power	0 (MSB)
Genset Supplying Load	1
Genset Running	2
Not in Auto	3
High Battery Voltage	4
Low Battery Voltage	5
Charger AC Failure	6
Fail to Start	7
Low Coolant Temperature	8
Pre-High Engine Temperature	9
High Engine Temperature	10
Pre-Low Oil Pressure	11
Low Oil Pressure	12
Overspeed	13
Low Coolant Level	14
Low Fuel Level	15 (LSB)

<sup>5</sup> ES State	
Digital Value	Description
0	Standby
1	Dead Bus Close
2	Synchronizing
3	Load Share
4	Load Govern

<sup>6</sup> Load Share State	
Digital Value	Description
0	Not in Load Share
1	Track Load
2	Ramp Load
3	Ramp Unload
4	Load Demand Shutdown

<b><sup>7</sup>Load Govern State KW</b>	
<b>Digital Value</b>	<b>Description</b>
0	Not Applicable
1	Ramp Load
2	Track Target Load
3	Ramp Unload
4	Ramp Unload Done

<b><sup>9</sup>Genset CB Position</b>	
<b>Digital Value</b>	<b>Description</b>
0	Open
1	Closed
2	Unavailable
3	Inhibit

<b><sup>8</sup>Load Govern State KVAR</b>	
<b>Digital Value</b>	<b>Description</b>
0	Not Applicable
1	Ramp Load
2	Track Target Load
3	Ramp Unload
4	Ramp Unload Done

<b><sup>10</sup>Utility CB Position</b>	
<b>Digital Value</b>	<b>Description</b>
0	Open
1	Closed
2	Unavailable
3	Inhibit

**TABLE 13. MODLON REGISTER MAPPING INFORMATION – FT-10 NETWORK (OPTION 2)  
AUTOMATIC TRANSFER SWITCH CONTROL COMMUNICATIONS MODULE (CCM-T)**

Structure	Data Point	ModBus Registers					Scaling		
		NCM[0]	NCM[1]	NCM[2]	NCM[3]	NCM[4]	Multiplier	Offset	Units
nvoATSSStatus	Name [0,1]	41001	41101	41201	41301	41401			
	Name [2,3]	41002	41102	41202	41302	41402			
	Name [4,5]	41003	41103	41203	41303	41403			
	Name [6,7]	41004	41104	41204	41304	41404			
	Name [8,9]	41005	41105	41205	41305	41405			
	Name [10,11]	41006	41106	41206	41306	41406			
	Name [12,13]	41007	41107	41207	41307	41407			
	Name [14,15]	41008	41108	41208	41308	41408			
	Device Type	41009	41109	41209	41309	41409			
	Mode <sup>1</sup>	41010	41110	41210	41310	41410			
	State <sup>2</sup>	41011	41111	41211	41311	41411			
	Fault Code	41012	41112	41212	41312	41412			
	Fault Type <sup>3</sup>	41013	41113	41213	41313	41413			
	Percent Amps	41014	41114	41214	41314	41414	0.5		%
	Total kW	41015	41115	41215	41315	41415			
nvoACDataLoad	NFPA 110 <sup>4</sup>	41016	41116	41216	41316	41416			
	Extended <sup>5</sup>	41017	41117	41217	41317	41417			
	Frequency	41018	41118	41218	41318	41418	0.1		Hz
	Total pf	41019	41119	41219	41319	41419	0.00005		PF
	Total kva	41020	41120	41220	41320	41420	1.0		KVA
	Total kW	41021	41121	41221	41321	41421	1.0		KW
	Total kvar	41022	41122	41222	41322	41422	1.0		KVAR
	Volts ab	41023	41123	41223	41323	41423	1.0		Volts
	Volts bc	41024	41124	41224	41324	41424	1.0		Volts
	Volts ca	41025	41125	41225	41325	41425	1.0		Volts
	Volts a	41026	41126	41226	41326	41426	1.0		Volts
	Volts b	41027	41127	41227	41327	41427	1.0		Volts
	Volts c	41028	41128	41228	41328	41428	1.0		Volts
	Amps a	41029	41129	41229	41329	41429	1.0		Amps
	Amps b	41030	41130	41230	41330	41430	1.0		Amps
	Amps c	41031	41131	41231	41331	41431	1.0		Amps
	Percent Amps a	41032	41132	41232	41332	41432	0.5		%
	Percent Amps b	41033	41133	41233	41333	41433	0.5		%
	Percent Amps c	41034	41134	41234	41334	41434	0.5		%
Control	Test	41035	41135	41235	41335	41435			
	Reset	41036	41136	41236	41336	41436			
							Data = Multiplier x (Register + Offset)		

<sup>1</sup> <b>Mode</b>	
<b>Digital Value</b>	<b>Description</b>
0	Test
1	Utility/Genset
2	Utility/Utility
3	Genset/Genset

<sup>2</sup> <b>State</b>	
<b>Digital Value</b>	<b>Description</b>
0	Neutral Position
1	Source 1 Connected
2	Source 2 Connected
3	Source 1 and 2 Connected

<sup>3</sup> <b>Fault Type</b>	
<b>Digital Value</b>	<b>Description</b>
0	No Faults
1	Warning

<sup>4</sup> <b>NFPA 110</b>	
<b>Description</b>	<b>Bit</b>
Source 1 Connected	0 (MSB)
Source 2 Connected	1
N/A	2
Not In Auto	3
N/A	4
N/A	5
Charger AC Failure	6
N/A	7
N/A	8
N/A	9
N/A	10
N/A	11
N/A	12
N/A	13
N/A	14
N/A	15 (LSB)

<sup>5</sup> <b>Extended</b>	
<b>Description</b>	<b>Bit</b>
Source 1 Available	0 (MSB)
Source 2 Available	1
Source 1 Connected	2
Source 2 Connected	3
ATS Common Alarm	4
Not In Auto	5
Test / Exercise in Progress	6
Low Battery Voltage	7
Load Shed	8
Transfer Inhibit	9
Retransfer Inhibit	10
Fail to Close	11
Fail to Disconnect	12
Fail to Synchronize	13
Bypass to Source 1	14
Bypass to Source 2	15 (LSB)

**TABLE 14. MODLON REGISTER MAPPING INFORMATION – FT-10 NETWORK (OPTION 2)  
DIGITAL INPUT/OUTPUT MODULE (DIM)**

Structure	Data Point	ModBus Register	
		DIM[0]	DIM[1]
nvolOStatus	relay 1	42000	42100
	relay 2	42001	42101
	relay 3	42002	42102
	relay 4	42003	42103
	relay 5	42004	42104
	relay 6	42005	42105
	relay 7	42006	42106
	relay 8	42007	42107
	relay 9	42008	42108
	relay 10	42009	42109
	relay 11	42010	42110
	relay 12	42011	42111
	relay 13	42012	42112
	relay 14	42013	42113
	relay 15	42014	42114
	relay 16	42015	42115
	input 1	42016	42116
	input 2	42017	42117
	input 3	42018	42118
	input 4	42019	42119
	input 5	42020	42120
	input 6	42021	42121
	input 7	42022	42122
	input 8	42023	42123
Control	nvi16RelayA	42024	42124

**TABLE 15. MODLON REGISTER MAPPING INFORMATION – FT-10 NETWORK (OPTION 3) PARALLELING PCC GENSET (CCM-G) (SHEET 1 OF 3)**

Structure	Data Point	ModBus Registers										Scaling	
		GEN[0]	GEN[1]	GEN[2]	GEN[3]	GEN[4]	GEN[5]	GEN[6]	GEN[7]	GEN[8]	GEN[9]		
nvoGenStatus	Name [0,1]	40001	40101	40201	40301	40401	40501	40601	40701	40801	40901		
	Name [2,3]	40002	40102	40202	40302	40402	40502	40602	40702	40802	40902		
	Name [4,5]	40003	40103	40203	40303	40403	40503	40603	40703	40803	40903		
	Name [6,7]	40004	40104	40204	40304	40404	40504	40604	40704	40804	40904		
	Name [8,9]	40005	40105	40205	40305	40405	40505	40605	40705	40805	40905		
	Name [10,11]	40006	40106	40206	40306	40406	40506	40606	40706	40806	40906		
	Name [12,13]	40007	40107	40207	40307	40407	40507	40607	40707	40807	40907		
	Name [14,15]	40008	40108	40208	40308	40408	40508	40608	40708	40808	40908		
Device Type	40009	40109	40209	40309	40409	40509	40609	40709	40809	40909			
Control Switch	40010	40110	40210	40310	40410	40510	40610	40710	40810	40910			
State <sup>1</sup>	40011	40111	40211	40311	40411	40511	40611	40711	40811	40911			
Fault Code*	40012	40112	40212	40312	40412	40512	40612	40712	40812	40912			
Fault Type <sup>2</sup>	40013	40113	40213	40313	40413	40513	40613	40713	40813	40913			
Percent kW	40014	40114	40214	40314	40414	40514	40614	40714	40814	40914	0.5	%	
Total kW	40015	40115	40215	40315	40415	40515	40615	40715	40815	40915			
NFPA 110 <sup>3</sup>	40016	40116	40216	40316	40416	40516	40616	40716	40816	40916			
Extended <sup>4</sup>	40017	40117	40217	40317	40417	40517	40617	40717	40817	40917			
nvoGenACData	Frequency	40018	40118	40218	40318	40418	40518	40618	40718	40818	40918	0.1	Hz
	Total pf	40019	40119	40219	40319	40419	40519	40619	40719	40819	40919	0.00005	PF
	Total kva	40020	40120	40220	40320	40420	40520	40620	40720	40820	40920	1.0	KVA
	Total kW	40021	40121	40221	40321	40421	40521	40621	40721	40821	40921	1.0	KW
	Total kvar	40022	40122	40222	40322	40422	40522	40622	40722	40822	40922	1.0	KVAR
	Volts ab	40023	40123	40223	40323	40423	40523	40623	40723	40823	40923	1.0	Volts
Volts bc	40024	40124	40224	40324	40424	40524	40624	40724	40824	40924	1.0	Volts	
Volts ca	40025	40125	40225	40325	40425	40525	40625	40725	40825	40925	1.0	Volts	
Volts a	40026	40126	40226	40326	40426	40526	40626	40726	40826	40926	1.0	Volts	
Volts b	40027	40127	40227	40327	40427	40527	40627	40727	40827	40927	1.0	Volts	
Volts c	40028	40128	40228	40328	40428	40528	40628	40728	40828	40928	1.0	Volts	
Amps a	40029	40129	40229	40329	40429	40529	40629	40729	40829	40929	1.0	Amps	
Amps b	40030	40130	40230	40330	40430	40530	40630	40730	40830	40930	1.0	Amps	
Amps c	40031	40131	40231	40331	40431	40531	40631	40731	40831	40931	1.0	Amps	
Percent Amps a	40032	40132	40232	40332	40432	40532	40632	40732	40832	40932	0.5	%	
Percent Amps b	40033	40133	40233	40333	40433	40533	40633	40733	40833	40933	0.5	%	
Percent Amps c	40034	40134	40234	40334	40434	40534	40634	40734	40834	40934	0.5	%	

\* Fault codes are listed in the genset Operator's Service Manuals.

Data = Multiplier x (Register + Offset)

**TABLE 15. MODLON REGISTER MAPPING INFORMATION – FT-10 NETWORK (OPTION 3) PARALLELING PCC GENSET (CCM-G) (SHEET 2 OF 3)**

Structure	Data Point	ModBus Registers									Scaling	
		GEN[0]	GEN[1]	GEN[2]	GEN[3]	GEN[4]	GEN[5]	GEN[6]	GEN[7]	GEN[8]	GEN[9]	
nvoGen EngData	Battery Voltage	40035	40135	40235	40335	40435	40535	40635	40735	40835	40935	0.1
	Oil Pressure	40036	40136	40236	40336	40436	40536	40636	40736	40836	40936	0.1
	Oil Temp (see Note 2)	40037	40137	40237	40337	40437	40537	40637	40737	40837	40937	0.1
	Coolant Temp	40038	40138	40238	40338	40438	40538	40638	40738	40838	40938	0.1
	Misc Temp 1 (see Note 4)	40039	40139	40239	40339	40439	40539	40639	40739	40839	40939	0.1
	Misc Temp 2 (see Note 4)	40040	40140	40240	40340	40440	40540	40640	40740	40840	40940	0.1
	Fuel Rate (see Note 3)	40041	40141	40241	40341	40441	40541	40641	40741	40841	40941	0.01
	Engine RPM	40042	40142	40242	40342	40442	40542	40642	40742	40842	40942	1.0
	Engine Starts	40043	40143	40243	40343	40443	40543	40643	40743	40843	40943	1.0
	Eng Runtime (High) (see Notes 1 and 5)	40044	40144	40244	40344	40444	40544	40644	40744	40844	40944	
	Eng Runtime (Low)	40045	40145	40245	40345	40445	40545	40645	40745	40845	40945	0.1
	Total kwh (High) (see Note 1)	40046	40146	40246	40346	40446	40546	40646	40746	40846	40946	
	Total kwh (Low)	40047	40147	40247	40347	40447	40547	40647	40747	40847	40947	1.0
	Total Fuel (High) (see Notes 1 and 3)	40048	40148	40248	40348	40448	40548	40648	40748	40848	40948	
	Total Fuel (Low)	40049	40149	40249	40349	40449	40549	40649	40749	40849	40949	0.01
												Gal

NOTES:

- For the Data Points Engine Runtime, the Total kwh and Total Fuel for the two registers designated as high and low are put together as an unsigned double integer. This is accomplished by multiplying the value in the high register by 65536 and adding it to the value in the low register. Most software packages automatically perform this calculation if the value is simply identified as an unsigned double integer.
- Value not supported in the 3200 controller.
- Value not supported in the 3100 controller.
- Value not supported.
- With 3100 and 2100 controllers, the units are hours. With the 3200 controller, the units are seconds. The multiplier is always 0.1

For all 3100 controllers, the values given are based on using EEPROM firmware, version 2.0 or greater. The values for Engine Runtime and Total kwh are not available on QST-30 gensets.

TABLE 15. MODLON REGISTER MAPPING INFORMATION – FT-10 NETWORK (OPTION 3) PARALLELING PCC GENSET (CCM-G) (SHEET 3 OF 3)

Structure	Data Point	ModBus Registers									Scaling	
		GEN[0]	GEN[1]	GEN[2]	GEN[3]	GEN[4]	GEN[5]	GEN[6]	GEN[7]	GEN[8]		
nvoGenParaData	Frequency	40050	40150	40250	40350	40450	40550	40650	40750	40850	40950	0.1
	Volts ab	40051	40151	40251	40351	40451	40551	40651	40751	40851	40951	1.0
	Volts bc	40052	40152	40252	40352	40452	40552	40652	40752	40852	40952	1.0
	Volts ca	40053	40153	40253	40353	40453	40553	40653	40753	40853	40953	1.0
	Volts a	40054	40154	40254	40354	40454	40554	40654	40754	40854	40954	1.0
	Volts b	40055	40155	40255	40355	40455	40555	40655	40755	40855	40955	1.0
	Volts c	40056	40156	40256	40356	40456	40556	40656	40756	40856	40956	1.0
	Customer Faults	40057	40157	40257	40357	40457	40557	40657	40757	40857	40957	
	Network Faults	40058	40158	40258	40358	40458	40558	40658	40758	40858	40958	
	Custom	40059	40159	40259	40359	40459	40559	40659	40759	40859	40959	
ES State <sup>5</sup>	ES State <sup>6</sup>	40060	40160	40260	40360	40460	40560	40660	40760	40860	40960	
	Load Share State <sup>6</sup>	40061	40161	40261	40361	40461	40561	40661	40761	40861	40961	
	Load Govern State Kw <sup>7</sup>	40062	40162	40262	40362	40462	40562	40662	40762	40862	40962	
	Load Govern State kvar <sup>8</sup>	40063	40163	40263	40363	40463	40563	40663	40763	40863	40963	
	Genset CB Position <sup>9</sup>	40064	40164	40264	40364	40464	40564	40664	40764	40864	40964	
	Utility CB Position <sup>10</sup>	40065	40165	40265	40365	40465	40565	40665	40765	40865	40965	
	Genset Control	Start/Stop	40066	40166	40266	40366	40466	40566	40666	40766	40866	40966
	Reset	40067	40167	40267	40367	40467	40567	40667	40767	40867	40967	

\* Fault codes are listed in the genset Operator's Service Manuals.

Data = Multiplir x (Reg + Offset)

1State		
Digital Value	Description	Bit
0	Stopped	0 (MSB)
1	Start Pending	1
2	Warmup at Idle	2
3	Running	3
4	Cooldown at Rated	4
5	Cooldown at Idle	5

2Fault Type		
Digital Value	Description	Bit
0	Normal	8
1	Warning	9
2	Derate	10
3	Shutdown with Cooldown	11
4	Shutdown	12

3NFPA 110		
Description	Bit	Digital Value
Normal Power	0 (MSB)	15 (LSB)
Genset Supplying Load	1	
Genset Running	2	
Not in Auto	3	
High Battery Voltage	4	
Low Battery Voltage	5	
Charger AC Failure	6	
Fail to Start	7	
Low Coolant Temperature	8	
Pre-High Engine Temperature	9	
High Engine Temperature	10	
Pre-Low Oil Pressure	11	
Low Oil Pressure	12	
Overspeed	13	
Low Coolant Level	14	
Low Fuel Level	15 (LSB)	

4Extended		
Digital Value	Description	Bit
Check Genset	0 (MSB)	0
Ground Fault	1	1
High AC Voltage	2	2
Low AC Voltage	3	3
Under Frequency	4	4
Overload	5	
Overcurrent	6	
Short Circuit	7	
Reverse KW	8	
Reverse KVAR	9	
Fail to Sync	10	
Fail to Close	11	
Load Demand	12	
Genset Circuit Breaker Tripped	13	
Utility Circuit Breaker Tripped	14	
Emergency Stop	15 (LSB)	

5ES State		
Digital Value	Description	Bit
0	Standby	0
1	Dead Bus Close	1
2	Synchronizing	2
3	Load Share	3
4	Load Govern	4

6Load Share State		
Digital Value	Description	Bit
0	Not in Load Share	0
1	Track Load	1
2	Ramp Load	2
3	Ramp Unload	3
4	Load Demand Shutdown	4

7Load Govern State KW		
Digital Value	Description	Bit
0	Not Applicable	0
1	Ramp Load	1
2	Track Target Load	2
3	Ramp Unload	3
4	Ramp Unload Done	4

8Load Govern State KVAR		
Digital Value	Description	Bit
0	Not Applicable	0
1	Ramp Load	1
2	Track Target Load	2
3	Ramp Unload	3
4	Ramp Unload Done	4

9Genset CB Position		
Digital Value	Description	Bit
0	Open	0
1	Closed	1
2	Unavailable	2
3	Inhibit	3

10Utility CB Position		
Digital Value	Description	Bit
0	Open	0
1	Closed	1
2	Unavailable	2
3	Inhibit	3

TABLE 16. MODLON REGISTER MAPPING INFORMATION - FT-10 NETWORK (OPTION 3)  
AUTOMATIC TRANSFER SWITCH CONTROL COMMUNICATIONS MODULE (CCM-T) (SHEET 1 OF 2)

Structure	Data Point	ModBus Registers							Scaling					
		NCM[0]	NCM[1]	NCM[2]	NCM[3]	NCM[4]	NCM[5]	NCM[6]	NCM[7]	NCM[8]	NCM[9]	Multiplier	Offset	Units
nvoATSStatus	Name [0,1]	40001	40101	40201	40301	40401	40501	40601	40701	40801	40901			
	Name [2,3]	40002	40102	40202	40302	40402	40502	40602	40702	40802	40902			
	Name [4,5]	40003	40103	40203	40303	40403	40503	40603	40703	40803	40903			
	Name [6,7]	40004	40104	40204	40304	40404	40504	40604	40704	40804	40904			
	Name [8,9]	40005	40105	40205	40305	40405	40505	40605	40705	40805	40905			
	Name [10,11]	40006	40106	40206	40306	40406	40506	40606	40706	40806	40906			
	Name [12,13]	40007	40107	40207	40307	40407	40507	40607	40707	40807	40907			
	Name [14,15]	40008	40108	40208	40308	40408	40508	40608	40708	40808	40908			
Device Type	40009	40109	40209	40309	40409	40509	40609	40709	40809	40909				
Mode <sup>1</sup>	40010	40110	40210	40310	40410	40510	40610	40710	40810	40910				
State <sup>2</sup>	40011	40111	40211	40311	40411	40511	40611	40711	40811	40911				
Fault Code	40012	40112	40212	40312	40412	40512	40612	40712	40812	40912				
Fault Type <sup>3</sup>	40013	40113	40213	40313	40413	40513	40613	40713	40813	40913				
Percent Amps	40014	40114	40214	40314	40414	40514	40614	40714	40814	40914	0.5	%		
Total kW	40015	40115	40215	40315	40415	40515	40615	40715	40815	40915				
NFPA 110 <sup>4</sup>	40016	40116	40216	40316	40416	40516	40616	40716	40816	40916				
Extended <sup>5</sup>	40017	40117	40217	40317	40417	40517	40617	40717	40817	40917				
nvoACDataLoad	Frequency	40018	40118	40218	40318	40418	40518	40618	40718	40818	40918	0.1	Hz	
	Total pf	40019	40119	40219	40319	40419	40519	40619	40719	40819	40919	0.00005	PF	
	Total kva	40020	40120	40220	40320	40420	40520	40620	40720	40820	40920	1.0	KVA	
	Total kW	40021	40121	40221	40321	40421	40521	40621	40721	40821	40921	1.0	KW	
	Total kvar	40022	40122	40222	40322	40422	40522	40622	40722	40822	40922	1.0	kVAR	
	Volts ab	40023	40123	40223	40323	40423	40523	40623	40723	40823	40923	1.0	Volts	
	Volts bc	40024	40124	40224	40324	40424	40524	40624	40724	40824	40924	1.0	Volts	
	Volts ca	40025	40125	40225	40325	40425	40525	40625	40725	40825	40925	1.0	Volts	
	Volts a	40026	40126	40226	40326	40426	40526	40626	40726	40826	40926	1.0	Volts	
	Volts b	40027	40127	40227	40327	40427	40527	40627	40727	40827	40927	1.0	Volts	
	Volts c	40028	40128	40228	40328	40428	40528	40628	40728	40828	40928	1.0	Volts	
Amps a	40029	40129	40229	40329	40429	40529	40629	40729	40829	40929	1.0	Amps		
Amps b	40030	40130	40230	40330	40430	40530	40630	40730	40830	40930	1.0	Amps		
Amps c	40031	40131	40231	40331	40431	40531	40631	40731	40831	40931	1.0	Amps		
Percent Amps a	40032	40132	40232	40332	40432	40532	40632	40732	40832	40932	0.5	%		
Percent Amps b	40033	40133	40233	40333	40433	40533	40633	40733	40833	40933	0.5	%		
Percent Amps c	40034	40134	40234	40334	40434	40534	40634	40734	40834	40934	0.5	%		

Data = Multiplier x (Register + Offset)

**TABLE 16. MODLON REGISTER MAPPING INFORMATION – FT-10 NETWORK (OPTION 3)  
AUTOMATIC TRANSFER SWITCH CONTROL COMMUNICATIONS MODULE (CCM-T) (SHEET 2 OF 2)**

Structure	Data Point	ModBus Registers	Scaling											
		NCM[0]	NCM[1]	NCM[2]	NCM[3]	NCM[4]	NCM[5]	NCM[6]	NCM[7]	NCM[8]	NCM[9]	Multiplier	Offset	Units
nvoACDataSrc1	Frequency	40035	40135	40235	40335	40435	40535	40635	40735	40835	40935	0.1		Hz
	Total pf	40036	40136	40236	40336	40436	40536	40636	40736	40836	40936	0.00005		PF
	Total kva	40037	40137	40237	40337	40437	40537	40637	40737	40837	40937	1.0		KVA
	Total kW	40038	40138	40238	40338	40438	40538	40638	40738	40838	40938	1.0		KW
	Total kvar	40039	40139	40239	40339	40439	40539	40639	40739	40839	40939	1.0		kVAR
	Volts ab	40040	40140	40240	40340	40440	40540	40640	40740	40840	40940	1.0		Volts
	Volts bc	40041	40141	40241	40341	40441	40541	40641	40741	40841	40941	1.0		Volts
	Volts ca	40042	40142	40242	40342	40442	40542	40642	40742	40842	40942	1.0		Volts
	Volts a	40043	40143	40243	40343	40443	40543	40643	40743	40843	40943	1.0		Volts
	Volts b	40044	40144	40244	40344	40444	40544	40644	40744	40844	40944	1.0		Volts
	Volts c	40045	40145	40245	40345	40445	40545	40645	40745	40845	40945	1.0		Volts
	Amps a	40046	40146	40246	40346	40446	40546	40646	40746	40846	40946	1.0		Amps
	Amps b	40047	40147	40247	40347	40447	40547	40647	40747	40847	40947	1.0		Amps
	Amps c	40048	40148	40248	40348	40448	40548	40648	40748	40848	40948	1.0		Amps
	Percent Amps a	40049	40149	40249	40349	40449	40549	40649	40749	40849	40949	0.5		%
	Percent Amps b	40050	40150	40250	40350	40450	40550	40650	40750	40850	40950	0.5		%
	Percent Amps c	40051	40151	40251	40351	40451	40551	40651	40751	40851	40951	0.5		%
nvoACDataSrc2	Frequency	40052	40152	40252	40352	40452	40552	40652	40752	40852	40952	0.1		Hz
	Total pf	40053	40153	40253	40353	40453	40553	40653	40753	40853	40953	0.00005		PF
	Total kva	40054	40154	40254	40354	40454	40554	40654	40754	40854	40954	1.0		KVA
	Total kW	40055	40155	40255	40355	40455	40555	40655	40755	40855	40955	1.0		KW
	Total kvar	40056	40156	40256	40356	40456	40556	40656	40756	40856	40956	1.0		kVAR
	Volts ab	40057	40157	40257	40357	40457	40557	40657	40757	40857	40957	1.0		Volts
	Volts bc	40058	40158	40258	40358	40458	40558	40658	40758	40858	40958	1.0		Volts
	Volts ca	40059	40159	40259	40359	40459	40559	40659	40759	40859	40959	1.0		Volts
	Volts a	40060	40160	40260	40360	40460	40560	40660	40760	40860	40960	1.0		Volts
	Volts b	40061	40161	40261	40361	40461	40561	40661	40761	40861	40961	1.0		Volts
	Volts c	40062	40162	40262	40362	40462	40562	40662	40762	40862	40962	1.0		Volts
	Amps a	40063	40163	40263	40363	40463	40563	40663	40763	40863	40963	1.0		Amps
	Amps b	40064	40164	40264	40364	40464	40564	40664	40764	40864	40964	1.0		Amps
	Amps c	40065	40165	40265	40365	40465	40565	40665	40765	40865	40965	1.0		Amps
	Percent Amps a	40066	40166	40266	40366	40466	40566	40666	40766	40866	40966	0.5		%
	Percent Amps b	40067	40167	40267	40367	40467	40567	40667	40767	40867	40967	0.5		%
	Percent Amps c	40068	40168	40268	40368	40468	40568	40668	40768	40868	40968	0.5		%
Control	Test	40069	40169	40269	40369	40469	40569	40669	40769	40869	40969			
	Reset	40070	40170	40270	40370	40470	40570	40670	40770	40870	40970			

Data = Multiplrx (Reg + Offset)

5Extended		
	Description	Bit
	Source 1 Available	0 (MSB)
	Source 2 Available	1
	Source 1 Connected	2
	Source 2 Connected	3
	ATS Common Alarm	4
	Not In Auto	5
	Test / Exercise in Progress	6
	Low Battery Voltage	7
	Load Shed	8
	Transfer Inhibit	9
	Retransfer Inhibit	10
	Fail to Close	11
	Fail to Disconnect	12
	Fail to Synchronize	13
	Bypass to Source 1	14
	Bypass to Source 2	15 (LSB)

4NFPA 110		
	Description	Bit
	Source 1 Connected	0 (MSB)
	Source 2 Connected	1
N/A		2
	Not In Auto	3
N/A		4
N/A		5
	Charger AC Failure	6
N/A		7
N/A		8
N/A		9
N/A		10
N/A		11
N/A		12
N/A		13
N/A		14
N/A		15 (LSB)

1Mode	
Digital Value	Description
0	Test
1	Utility/Genset
2	Utility/Utility
3	Genset/Genset

2State	
Digital Value	Description
0	Neutral Position
1	Source 1 Connected
2	Source 2 Connected
3	Source 1 and 2 Connected

3Fault Type	
Digital Value	Description
0	No Faults
1	Warning