




Tsys vs Az for various shims. freq=8505 Pol:I RemoveBase.




Tsys vs Az for various shims. freq=8505 Pol:A RemoveBase.




Tsys vs Az for various shims. freq=8505 Pol:B RemoveBase.




Gain vs Az for various shims. freq=8505 Pol:I RemoveBase.




Gain vs Az for various shims. freq=8505 Pol:A RemoveBase.




Gain vs Az for various shims. freq=8505 Pol:B RemoveBase.




SEFD vs Az for various shims. freq=8505 Pol:I RemoveBase.




SEFD vs Az for various shims. freq=8505 Pol:A RemoveBase.




SEFD vs Az for various shims. freq=8505 Pol:B RemoveBase.




Az BmWidth vs Az for various shims. freq=8505 Pol:I RemoveBase.




Az BmWidth vs Az for various shims. freq=8505 Pol:A RemoveBase.




Az BmWidth vs Az for various shims. freq=8505 Pol:B RemoveBase.




El BmWidth vs Az for various shims. freq=8505 Pol:I RemoveBase.




El BmWidth vs Az for various shims. freq=8505 Pol:A RemoveBase.




El BmWidth vs Az for various shims. freq=8505 Pol:B RemoveBase.




Az/EI BmWdRatio vs Az for various shims. freq=8505 Pol:I RemoveBase.




Az/EI BmWdRatio vs Az for various shims. freq=8505 Pol:A RemoveBase.




Az/EI BmWdRatio vs Az for various shims. freq=8505 Pol:B RemoveBase.




Az Pointing error vs Az for various shims. freq=8505 Pol:I RemoveBase.




Az Pointing error vs Az for various shims. freq=8505 Pol:A RemoveBase.




Az Pointing error vs Az for various shims. freq=8505 Pol:B RemoveBase.



El pointing error vs Az for various shims. freq=8505 Pol:I RemoveBase.



El pointing error vs Az for various shims. freq=8505 Pol:A RemoveBase.



El pointing error vs Az for various shims. freq=8505 Pol:B RemoveBase.

